

https://verifone.cloud/docs/sca-functional-

specification/media_specifictn/ui_engage_device/disp_scrn_ui_eng_devc_m400

Updated: 23-Sep-2025

M400 - User Inteface

Idle Screen


The Idle Screen displays upon device power up, after reboot, and after transaction completion. SCA supports the following merchant controlled media areas: Idle Screen Video, Idle Screen Animation, and Idle Screen Full Image.



Note

Refer to Media File - Size and Formats for more information on Idle screen resolutions and media files.

Register POS



REGISTER command sends a 4-digit code to the device. Enter this code to register the POS. Once registered, the POS should run the Test MAC command to confirm the pairing worked.

Line Items Screen

The Line Item Screen displays when the POS sends start transaction message or interactively as the POS scans line items.

Description Display Items • Quantity Baseball \$5.98 • Description 4 Golf Balls \$.49 \$1,96 • Unit Price 8 Golf Tees \$.25 \$2.00 • Extended Price Coupon Redeemed -(\$.75) • Running Tax Total Tax \$.77 • Running Sub Total (optional) Total: \$9.83 • Coupons or Discounts

The Line Item Screen advertising area allows a number of images to be displayed in a sequential order.

Note

Refer to Media File - Size and Formats for more information on Line Item screen resolutions and media files.

	Line Items		
••• verifone	#1 Combo Meal #1 Combo Meal EmpDisc 1OffAnyPurch	1 \$ 1 \$ \$ \$	5.00 5.00 2.00 1.00
Tap, Insert or Swipe	Discount Sub Total Tax Total	\$ 999,999 \$ 999,999 \$ 999,999 \$ 999,999	9.99

Line Item (Split screen): Line Item Screen with advertisement area image. The Line Item Display advertising area can be configured to include consumer selection options.


Line	! Items		
#1 Combo Meal	1	s	5.00
#1 Combo Meal	1	\$	5.00
EmpDisc		\$	2.00
1OffAnyPurch		\$	1.00
Discount		< 90	9,999.99
Sub Total			9,999.99
Tax		\$ 99	9,999.99
Total		\$ 99	9,999.99
Tap, Inse	ert or Swipe		

Line Item (Full screen): Line Item Screen without advertisement area image.

Transaction Flows

Sale (EMV CT and CTLS with Quick chip enabled)

Sale - Tap



Sale - Insert

Tap, Insert or Swipe







Select the card entry mode: Insert or Swipe.

Sale USD \$2.00



Processing... Please Keep Card Inserted


Processing screen and card should be inserted.

TOTAL \$ 2.00

Enter PIN Or Press Enter To Continue



Tap the text box for keyboard input and type the PIN or press the Enter key to continue to next screen.




Authorization in progress screen.






The transaction is completed, and the card can be removed. After the card is removed the status screen is displayed, until the next command is sent.




This is the Status screen as Sale Approved.



This is the Status screen as Sale Declined.

Sale - Manual Entry - For the transactions with manual card entry, following are the additional screens to gather card details.

After three failed card swipe attempts, SCA will display 'Please Wait for the Cashier'. If the merchant configuration is enabled, then the device may next prompt for manual card entry.



Dis	play	Description
CREDIT	Type? PRIVATE LABEL ncel	Select the Card type and proceed to next screen.
Enter Expi	ry (MMYY): Enter	Tap the text box for keyboard input and type the expiration date in MMYY format. Press the green Enter key on the device keyboard. The device will next prompt for CVV Number.
Cancel	Enter	Tap the text box for keyboard input and type the Security Code. Press the green Enter key on the device keyboard.


Additional Sale Screens



This is the Card Read screen with payment brands.



Cancel by Customer - This screen will be displayed if the transaction is cancelled manually at any point.



Cancel by Timeout - This is the Status screen if the Sale is cancelled due to Time out.

Refund

Refund - Tap

Tap, Insert or Swipe







Select the card entry mode: Tap

Refund USD \$1.00




Authorizing

Authorization in progress screen.



Transaction is approved screen. After the transaction is complete, the device will return to the Idle Screen.



This is the status screen as Refund Declined if the transaction is not approved.

Refund - Insert

Display Description

Tap, Insert or Swipe







Select the card entry mode: Insert or Swipe.


Refund USD \$2.00




Processing... Please Keep Card Inserted

Processing screen and card should be inserted.

Display Description



Tap the text box for keyboard input and type the PIN or press the Enter key to continue to next screen.




Authorization is in progress screen.



The transaction is completed, and the card can be removed. After the card is removed the status screen is displayed, until the next command is sent.






This is the Status screen as Refund Approved.

Void

Display Description




Void transaction is processed, and authorization is in progress screen.



This is the Status screen as Voided (success).






Void declined status screen.

Optional Screens

Optional Screens are displayed during the Sale flow and these screens can be configured based on required parameters.

Welcome Screen






Description

This is the screen within the session when LINEITEMDISPLAY parameter should be set to 0 (disabled) and preswipe (SWIPE_AHEAD) field should be sent as 0 (disabled) in Start session command.



Description




This is the Welcome screen with Card read option.

Split Tender

Display

Description




Option to choose if the amount would be divided to two cards.

- Select No to enter the partial amount to pay.
- Select Yes to pay full amount in one card, and Card Read screen would be displayed.

Cash Back

Display


Description




Card Type/Payment Type Selection

Display

Description



Tip Selection




Loyalty Entry Method


Select Loyalty Entry Method Phone Card Skip Cancel

Description


Select **Phone** option to enter phone number or select **Card** option to go to Loyalty Card for card swipe or entering account number. Select **Skip** if Loyalty Entry Method is not required.

Phone Number






Loyalty Card



Device Command Screens

Donation			
WOULD YOU LIKE TO CONTRIIBUTE TO XYZ FOUNDATIONS TODAY?			
			Charity Donation.
\$5.00	\$10.00	\$15.00	
	Skip		
WOULD YOU LIKE TO SIGN UP FOR EMAIL COUPONS			
			Customer Question.
No		Yes	
PLEASE SELEC	T THE COMPANY YOU HAVE YOUR CAREER IN INDIA.	WORKED IN	
WORLD MARKETING	VERIFONE	FIRSTDATA	Customer Button.
TSYS	WIPRO	GIRMITI	





Credit Application - Tap the text box for keyboard input to type the name.

Disp	lay	Description
PLEASE ENTER YOUR	R PHONE NUMBER	
()	-	Credit Application - Tap the text box
		for keyboard input to type the phone number.
		number.
Cancel	Entor	
Cancel	Enter	
PLEASE ENTER YOUR	R PHONE NUMBER	
(999)999	9-9999	
		Credit Application - Once the number is added then press Enter.
		is added then press Enter.
Cancel	Enter	
DI FASS SAITED VOI	D CDOCC THEOME	
PLEASE ENTER YOU		Credit Application Top the text have
\$ 2555	5.55	Credit Application - Tap the text box for keyboard input to type the gross
		income and press Enter to confirm and the data will be processed as shown
		below.

Enter

Cancel

Display Description Credit Application - Details processing. Processing...Please Wait **Line Items** Buy 1 Get 1 on Pizzas Get 30% Discount Pay using Visa Card Sunday Special Holiday Gift Display left panel. Special Snacks Offers on Cookies Pay using Private Card Sleepwell Beds Get Pedigrees for Free Tax \$ 0.00 APPLY Cancel Total \$ 0.00 Ask us about upcoming sales! **Line Items**

\$ 0.00

\$ 0.00

Tax

Total

Tap, Insert or Swipe

