

PED status codes

These codes are set by [ped_Pairing\(\)](#).
[More...](#)

Macros

#define	PED_LINK_OK 0
#define	PED_NS_DONE 1
#define	PED_CERT_ERR 2
#define	PED_NS_ERR 3

Detailed Description

These codes are set by [ped_Pairing\(\)](#).

Macro Definition Documentation

◆ [PED_CERT_ERR](#)

```
#define PED_CERT_ERR 2
```

Set by [ped_Pairing\(\)](#): Error during certificate exchange.

◆ [PED_LINK_OK](#)

```
#define PED_LINK_OK 0
```

Set by [ped_Pairing\(\)](#): Link verification successful, no pairing needed.

◆ [PED_NS_DONE](#)

```
#define PED_NS_DONE 1
```

Set by [ped_Pairing\(\)](#): Link verification failed, pairing (Needham-Schroeder) successful.

◆ [PED_NS_ERR](#)

```
#define PED_NS_ERR 3
```

https://verifone.cloud/docs/application-development-kit-version-48/group__ped_status_codes

Updated: 05-Mar-2025

Set by [ped_Pairing\(\)](#): Error during pairing (Needham-Schroeder).