

Other Parameters

This configuration parameter is present in Config.usr1 file. This is not present in TranslateConfig.xml location.

Config.usr1/Parameter DLD Name	Description	Valid/Max Values
24HOURREBOOT	This parameter is used to set 24 hour reboot time. It requires a terminal reboot to get honored.	The format is hh:mm:ss. Example: 03:00:30. User can set the time.