

Bluetooth Parameters

This table describes the required parameters used for Bluetooth.

Config.usr1/Parameter DLD Name	Description	Valid/Max Values	Default Value	Name in PropertiesData.xml
BTSERVICENAME	Service Name for bluetooth communication, which is used by POS application. NOTE: This parameter has underscore (_) at the end of the name.	Alphanumeric, 9 <ul style="list-style-type: none"> • COM1 • COM2 • COM3 	[empty]	service_name
BTSPORT	Serial Port for bluetooth communication, that is being used for POS communication. NOTE: This parameter has underscore (_) at the end of the name.	Alphanumeric, 9 <ul style="list-style-type: none"> • COM1A for Apple platform • BT_SPP for Windows • BT_SPP for Android 	BT_SPP	serial_port