

Parameters Query

This command allows the POS to retrieve SCA parameter values from the payment device (TranslateConfig.xml).

Rules

The GET_PARM command is intended for non-payment purposes and is to be used outside of a payment transaction.

Configuration Parameters

There is no configuration parameter associated with this command functionality.

Message Interface

Refer to the below Protocol section for the command fields description and examples.

- [GET_PARM](#)