

Set Parameters

This command is used to set SCA parameters on the payment device. Direct to Processor implementations only. Not supported by TSYS Direct Engage.

Rules

1. The SET_PARM command is intended for non-payment purposes and is used outside of a payment transaction.
2. Perform a Query SAF to ensure no outstanding SAF records are present before changing MID/TID/URL values.

Configuration Parameters

Following are the configuration parameters which affect the operation

- LANEID
- PARM_MID
- PARM_TID
- PARM_PRIMURL
- PARM_SCNDURL

Message Interface

Refer to the below Protocol section for the command fields description and examples.

- [SET_PARM](#)