

SCA Coms Control Panel (CCP)

Coms Control Panel (CCP) feature has been integrated into SCA application to provide a better way to configure Networks on the device. To enable this feature, user needs to set ADVCOMMSENABLED parameter to Y, and this parameter will enable Comm Control Panel (CCP) menu inside SCA Configuration menu.

Refer to SCA Engage Application Guide for the details on Network Configuration flows using SCA CCP feature.

Refer to <u>Application Parameters</u> and <u>Interfaces Parameters</u> for the details on Interfaces parameters and other parameters relevant to SCA CCP.

Updated: 04-Dec-2024