

APM CP Application Parameters

The below table describes the configurable parameters from the Parameter Definition File `apm_params.vpdx` and the Parameter Form File `apm_params.vpfx`, which need to be imported on VHQ server for every APM CP application.

APM Parameters

Parameter Name	Description	Valid/Max Values	Default Value	Display Name
server	This defines the server URL path.	String. 12 – 100 characters	https://gsc.verifone.cloud/	Server URL
password	This is used for setting password.	String. 0 – 6 characters	254729	Settings Password
storeId	This is used to define the store ID.	String. 0 – 6 characters [empty]		Store ID
merchantId	This is used for merchant ID.	String. 0 – 6 characters [empty]		Merchant ID
terminalId	This is used to represent a device details from a specific facility/ restaurant/ or retail location.	String. 0 – 6 characters [empty]		Terminal ID
time	This defines timeout period.	Numeric. 10 – 480 digits	60	Timeout
interval	Polling interval.	Numeric. 1 – 5 digits	4	Polling Interval
demoMode	This is used to perform transactions in training mode.	True and False	False	Demo Mode
automaticCancel	This is used for Automatic cancel.	True and False	True	Automatic Cancel
posIdCheck	This is used to check the POS identity.	• Off • customerFacing • notification • confirmation	Off	Identity check