

SET_PARM

This command is used to set SCA parameters on the payment device. Direct to Processor implementations only. Not supported by TSYS Direct Engage.

Device UI Required: No

Request Packet

Field	Rule	Type	Minimum	Maximum	Value(s)	Description
FUNCTION_TYPE	Required	Static value	N/A	N/A	DEVICE	Type of function
COMMAND	Required	Static value	N/A	N/A	SET_PARM	Command name.
PARAM	Optional	Character	1			If the user wants to set multiple parameters, then each parameter should be separated by pipe symbol in request. Example: 1: TIP=PROMPT; 2: GRATUITYPERCENT1=1000 GRATUITYPERCENT2=1100
PARAM_MID	Optional	Numeric	1	20		Merchant Gateway ID
PARAM_TID	Optional	Numeric	1	20		Terminal ID
PARAM_LANE	Optional	Numeric	1	20		Lane ID
PARAM_HOST_IND	Required	List	1	20	<ul style="list-style-type: none"> • VANTIV (SCA 4.0 Vantiv) • FDRC (Engage First Data Rapid Connect) • VNTV (Engage Vantiv) • CHHC (Chase) 	Host to which the values correspond. Example: VANTIV
PARAM_ADMINURL	Optional	Character	1	80		Admin URL

Field	Rule	Type	Minimum	Maximum	Value(s)	Description
PARM_PRIMURL	Optional	Character	1	80		Primary URL
PARM_SCNDURL	Optional	Character	1	80		Secondary URL
PARM_USERNAME	Optional	Character	1	20		Username
PARM_PASSWORD	Optional	Character	1	20		Password
ARM_ALTMERCHID	Optional	Numeric	1	20		Alternative merchant ID
PARM_TIMEZONE	Optional	Numeric	1	20		Time zone
PARM_TOKEN_TYPE	Optional	Character	1	20		Token type
PARM_PARTNERID	Optional	Character	1	20		
PARM_TRANSPORT_KEY	Optional	Character	1	20		Transport key
POS_RECON	Optional	Character	1	30		POS reconciliation. POS Reconciliation field to be echoed back in response to POS. Example: RetailPOS1
COUNTER	Required	Numeric	1	10		COUNTER is used for a given MAC label. Each COUNTER should be higher than the last one. This is used to authenticate the POS. Example: 18

Field	Rule	Type	Minimum	Maximum	Value(s)	Description
MAC	Required	Base64 Encoded Data	N/A	N/A	N/A	Message Authentication Code. This is used to authenticate the POS.
MAC_LABEL	Required	Character	1	50		Associated label that tells the device which MAC_KEY to use to decrypt the value of MAC. This is used to authenticate the POS. Example: REG1

Example

Following is an example of request packet

```

<TRANSACTION>
<FUNCTION_TYPE>DEVICE</FUNCTION_TYPE>
<COMMAND>SET_PARM</COMMAND>
<PARAM>GRATUITYPERCENT1=1000 | GRATUITYPERCENT2=1100</PARAM>
<PARAM_HOST_IND>FDRC</PARAM_HOST_IND>
<COUNTER>1</COUNTER>
<MAC> ... </MAC>
<MAC_LABEL>REG2</MAC_LABEL>
</TRANSACTION>

```

Response Packet

Field	Type	Value	Description
RESPONSE_TEXT	Character		Processor response text. Example: VTP COMMND PROCESSED418
RESULT	Character		This indicates the Result details. Example: CAPTURED

Field	Type	Value	Description
RESULT_CODE	Numeric	Expected result code: -1, 4, 59001, 59006, 59040	This indicates the result code.
TERMINATION_STATUS	Character	SUCCESS and FAILURE	This indicates the transaction termination status. This is the overall status of the transaction irrespective of approved or declined. Like, if the output is generated then the status is SUCCESS and if no output is generated then the status will be FAILURE.
POS_RECON	Character		POS reconciliation field echoed back if sent in request. Example: RetailPOS1
COUNTER	Numeric		Echoes counter sent in the request. Example: 18

NOTE: After modification of the MID/TID/URLS/Lane ID or any host related parameters it is required to restart the application for the parameter to take an effect.

Example

Following is an example of response packet

```
<RESPONSE>
<RESPONSE_TEXT>Operation SUCCESSFUL</RESPONSE_TEXT>
<RESULT>OK</RESULT>
<RESULT_CODE>-1</RESULT_CODE>
<TERMINATION_STATUS>SUCCESS</TERMINATION_STATUS>
<COUNTER>144</COUNTER>
</RESPONSE>
```